



| No. | Part name | Material | QTY | Remark |
|-----|--------------------|----------|-----|--------|
| 01 | Cable | | 1 | |
| 03 | Upper cover | FC200 | 1 | |
| 06 | Bracket | FC200 | 1 | |
| 07 | Stator | | 1 | |
| 09 | Shaft end | SUS403 | 1 | |
| 10 | Auto-cut | | 1 | |
| 11 | Bearing fixer | SPCC | 1 | |
| 12 | Centrifugal switch | | 1 | |
| 14R | Capacitor | | 1 | |
| 14S | Start capacitor | | 1 | |
| 16 | Motor frame | SUS304 | 1 | |
| 17 | Lubricant | | | |
| 19 | Bearing bracket | FC200 | 1 | |

| No. | Part name | Material | QTY | Remark |
|-----|--------------|---------------------|-----|--------|
| 20A | Bearing | | 1 | |
| 20B | Bearing | | 1 | |
| 21 | M.seal | CA / CE & SIC / SIC | 1 | |
| 25 | Oil seal | NBR | 1 | |
| 26 | Casing | FC200 | 1 | |
| 27 | Impeller | FC200 | 1 | |
| 28 | Casing cover | FC200 | 1 | |
| 30 | Footing | FC200 | 1 | |
| 31 | Strainer | SUS304 | 1 | |
| 41 | Handle | SUS304 | 1 | |
| 46 | Impeller key | SUS304 | 1 | |
| 47 | Packing | | | |